



★ This dashed line shows where an optional lead overlay may be placed to add definition to the frog. After all the soldering of the project is complete, one can either use sticky overlay lead or cut out the heart of lead and silicone the lead to the glass. The joint between the overlay and the lead in the panel should be soldered.

Glass used in Santa Frog art: B6212-00, S200RR, S359-1, 25216G.

Copyright © 2003 Alpine Stained Glass & Door
<http://www.alpineglass.com>